





- P2: Safety instructions
P3: Contents
P4: Assembly instructions
P7: Application

SAFETY INSTRUCTIONS: CARRÉ L-BODY

IMPORTANT SAFETY INSTRUCTIONS
Before using an electrical unit, basic precautions should always be followed, including the following:


DANGER - To reduce the risk of electric shock:
1. This SECURE DISPLAY SYSTEM contains electronic components.
Do not open these without a qualified electrician or an official Top Vision dealer.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:
1. Close supervision is necessary when this unit is used by, or near children, invalids, or disabled persons.
2. Use this unit only for its intended use as described in this manual.
Do not use attachments not recommended by the manufacturer.
3. Never operate this unit if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the product to a service center for examination and repair.
4. Never drop or insert any object into any opening other than the intended use of presenting sunglasses.
5. Do not use outdoors / for indoor use only!


MAINTENANCE INSTRUCTIONS - Instructions for cleaning and user maintenance operations:
1. The exterior of a SECURE DISPLAY SYSTEM may only be cleaned with a non-static brush.
2. The SECURE DISPLAY SYSTEM has no user serviceable parts. All malfunctioning or damaged components are to be replaced by a service representative duly authorized by Top Vision Group BV or an official Top Vision dealer.

INTENDED USE
1. The indented use of the Secure Display System is to display eyewear frames and sunglasses.
2. This product is for commercial use only.


PACKAGING CONTENT “3P” - CONTENIDO DEL EMBALAJE “3P”




L-Body bracket
43014
1x



L-Body housing
CLB.3.TW-575
575 x 230 x 92 mm
1x




Screw
art. 95068
3,9 x 38mm
4x




Wall plug
art. 95092
S6
4x


PACKAGING CONTENT “5P” - CONTENIDO DEL EMBALAJE “5P”



L-Body bracket
27698
1x



L-Body housing
CLB.5.TW-930
930 x 230 x 92 mm
1x



Screw
art. 95068
3,9 x 38mm
4x




Wall plug
art. 95092
S6
4x


REQUIRED TOOLS - HERRAMIENTAS NECESARIAS




Hexagon wrench #2.5
art. 92047




Drill Ø2mm
Drill Ø6mm




Screwdriver P2



Level



Pencil



Tape measure

- P2: Instrucciones de seguridad
P3: Contenido
P4: Instrucciones de montaje
P7: Aplicación

INSTRUCCIONES IMPORTANTES DE SEGURIDAD: CARRÉ L-BODY


Cuando se usa una unidad eléctrica se deben tomar precauciones básicas, incluidas las siguientes:

PELIGRO – Para reducir el riesgo de descarga eléctrica:
1. Este expositor contiene componentes electrónicos. No abrirlo sin la presencia de un electricista cualificado o un profesional de Top Vision.


AVISO – Para reducir el riesgo de quemaduras, fuego, descargas eléctricas o daños a personas:
1. Es necesaria la supervisión cuando la barra la usen niños o disminuidos.
2. Usar la barra única y exclusivamente para el uso descrito en el manual.
3. No encender esta unidad si el cable o el enchufe están dañados, si no funciona bien, si se ha caído o ha sido dañada o si ha tenido contacto con agua. Devolver el expositor al centro de servicio para su examinación y reparación.
4. Nunca intentar meter ningún objeto en ninguna de las cerraduras que no sea la tarjeta Top Vision.
5. No usar al aire libre, son para interior únicamente.

INSTRUCCIONES PARA EL MANTENIMIENTO DE LAS OPERACIONES:
Instrucciones para las operaciones de limpieza y mantenimiento del usuario
1. El exterior de un expositor sólo se puede limpiar con un cepillo no estático.
2. En ninguno de los expositores se pueden reemplazar las piezas. Todas las que no funcionen deben ser reemplazadas por personas totalmente autorizadas por TVG o por personal de TVG.



USO DEL EXPOSITOR
1. El expositor es para exponer gafas de sol y monturas.
2. Este producto es sólo para uso comercial.




Drill instructions L-Body 3 positions




Advised distance: 240mm
Distance conseillée : 240mm




Drill instructions L-Body 5 positions




Advised distance: 240mm
Distance conseillée : 240mm





1




Pencil



Tape measure



2




Wooden wall: Drill Ø2mm
Stone wall: Drill Ø6mm

Holz : Bohrloch 2mm
Steinwand : Bohrloch 6 mm


Pared de madera: taladro Drill Ø2m
Pared de piedra: taladro Ø6mm

Paroi en bois : perçage Ø2m
Mur en pierre : perçage de Ø6mm


Houten wand: Boor Ø2m
Stenen muur: Boor Ø6mm




3



Wall plug
art. 95093
S6
4x




4




L-Body bracket 3P
1x


or / o





L-Body bracket 5P
1x




Screwdriver
P2





Screw
art. 95068
3,9 x 38mm
4x



5




or / o




6




Hexagon wrench #2,5




Art. 16082
2x
M4x12




1




2



3



4





Frame Displays.com

22821 Silverbrook Center Dr.

Suite 140

Sterling, VA 20166

United States of America

Tel: 877-274-9300

info@framedisplays.com

www.framedisplays.com